CFMOTO ACCESSORY SETUP INSTRUCTION

GUARD, RADIATOR -- PN 6WWV-802030-5000

VALID FOR: MY2023 and Newer Ibex 800 S, Ibex 800 T

BEFORE YOU BEGIN: Read and understand the instructions before starting any work. Make sure that all parts are ready and that you have all the tools required for assembly.

NOTE: CFMOTO shall not be liable for any damage caused by incorrect assembly. CFMOTO recommends that all original accessories be assembled by an authorized CFMOTO dealer.

Before assembly, park the vehicle on a flat surface and turn off the key switch.


Zhejiang CFMOTO Power Co., Ltd. All rights reserved. Reproduction of this document, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.

MEANING OF SYMBOLS

- Indicates information with more details or tips.
- Indicates information of warning or danger.


PARTS LIST:

ITEM	PART NAME	PART NUMBER	QTY.	REMARK
1	GUARD, RADIATOR		1	
2	GUARD		1	
3	LOWER BRACKET, LH		1	
4	LOWER BRACKET, RH		1	
5	UPPER BRACKET		2	
6	SCREW M5×10	6GUV-801700-6000-20	8	
7	NUT M5	6GUV-801700-6000-24	8	
8	WASHER M5	6GUV-803000-6000-22	4	



TOOL LIST:


ITEM	DESCRIPTION	QTY.	REMARK
1	4mm ALLEN WRENCH	1	
2	5mm ALLEN WRENCH	1	
3	13mm SOCKET	1	Recommended tools
4	RUBBER HAMMER	1	
5	PROTECTIVE GLOVES	1	



Remove the plugs (C) and bolts (B) in turn, and then remove the front bumper support rod (A).

 ${\ensuremath{\rlap/}}$ Remove the bolts (D) on the lower of the radiator.

 Place the radiator guard (1) in the assembly position and clip the upper mounting point (E) into the radiator.
Align the radiator guard and lower radiator mount to the mounting holes, then install the previously removed bolts (D).



Install the front bumper support rod (A) back to its original position, fasten it with bolts (B), and then plug in the plugs (C).

BOLT (B)	M8	/	15-20N.m
----------	----	---	----------